

11TH GEN HONDA CIVIC CATCH CAN STAGE 1

TOOLS REQUIRED

14MM Socket
M4 Allen Key
Flat Screw Driver
Dremmel Tool

MATERIALS REQUIRED

| | | | | | | | |
|--|---|--|--|----|--|----|--|
| 1 | Remove the motor mount bolt. | 2 | Use Dremmel tool to create flathead bolts on hose clamps. | 3 | Loosen clamps and remove vent hose. | 4 | Prepare the Boomba Racing Catch Can Stage 1 Kit. |
|  |  |  |  | | | | |
| 5 | Make sure that the Catch Can's "IN" is on the left and "OUT" is on the right. | 6 | Mount Catch Can Bracket on Boomba Racing Catch Can. | 7 | Mount Boomba Racing Catch Can with bracket, spacer and provided bolt. | 9 | Grease the vent adaptors and insert hose adaptor on intake. |
|  |  |  |  | | | | |
| 10 | Install hose adaptor on OEM ventline. | 11 | Reinstall vent hose. | 12 | Install shorter vent hose on "OUT" port of catch can and route to intake manifold. | 13 | Install longer vent hose on "IN" port of catch can and route to the valve cover. |
|  |  |  |  | | | | |