

# CIVIC 11G

## SHIFT KNOB

### TOOLS REQUIRED

M14 wrench  
Small flat screw driver

### MATERIALS REQUIRED

None

1	Insert the flat screw driver between the shift knob and the snap ring. Pry the snap ring off.	2	Loosen up the jam nut under the shift knob. Remove the shift knob.	3	Install the Boomba Racing shift knob. Secure the jam nut.	4	Install the shift pattern insert in correct orientation. Install the snap ring.
							