

# ELANTRA N CATCH CAN S2

## TOOLS REQUIRED

M10 socket wrench  
4 MM allen wrench  
Flat screw driver  
Razor blade

## MATERIALS REQUIRED

<p><b>1</b></p>	<p>Prepare Elantra N Stage 2 mounting kit.</p>	<p><b>2</b></p>	<p>Secure the mounting bracket to the Catch Can. Connect the longer vent line to the "OUT". Connect the shorter vent line to the "IN" port. Secure the vent lines with the hose clamps.</p>
<p><b>3</b></p>	<p>Install the hose fittings to the vent lines. Secure the fittings with the hose clamps.</p>	<p><b>4</b></p>	<p>Remove the engine cover.</p>
<p><b>5</b></p>	<p>Cut the factory vent line.</p>	<p><b>6</b></p>	<p>Rotate the vent line connected to the valve cover around 180 degrees.</p>
<p><b>7</b></p>	<p>Mount the Catch Can beside the front passenger side headlight using the existing bolts. Connect the vent from the valve cover to the "IN" port. Connect the vent from the intake manifold to the "OUT" port.</p>	<p><b>8</b></p>	<p>Use the zip ties to dress up the vent hoses. Install the engine cover.</p>

