

# FORD MAVERICK MOTOR MOUNT

## TOOLS REQUIRED

M13 socket  
M15 socket  
M18 socket  
M21 socket  
T30 Torx bit

## MATERIALS REQUIRED

None

<p><b>1</b></p>	<p>Remove the front skid plate section.</p>	<p><b>2</b></p>	<p>Remove the skid plate.</p>
			
<p><b>5</b></p>	<p>Remove the main mount.</p>	<p><b>6</b></p>	<p>Prepare the Boomba Racing motor mount for installation.</p>
		<p><b>7</b></p>	<p>Install the main mount. <b>Do not tighten the screws.</b></p>
	<p><b>10</b></p>	<p><b>11</b></p>	<p>Reinstall the exhaust support bracket.</p>
			