

VOLKSWAGEN GTI Mk8

BOV ADAPTOR

TOOLS REQUIRED

T30 Torx bit
5 MM allen wrench

MATERIALS REQUIRED

None

1	Disconnect the wire connector.	2	Remove the mounting screws.	3	Prepare the Boomba Racing blow off valve adaptor.	4	Install the blow off valve with the provided screws. Reconnect the wire connector.
							