

KONA N CATCH CAN S1

TOOLS REQUIRED

M10 socket wrench
4 MM allen wrench
Razor blade

MATERIALS REQUIRED

<p>1</p>	<p>Prepare Kona N Stage 1 mounting kit.</p>	<p>2</p>	<p>Secure the mounting bracket to the Catch Can</p>
		<p>3</p>	<p>Mount the Catch Can beside the front driver side headlight using the existing bolts.</p> 
<p>4</p>	<p>Remove the engine cover.</p>	<p>5</p>	<p>Cut the factory vent line.</p> 
<p>6</p>	<p>Rotate the vent line connected to the valve cover around 45 degrees clockwise.</p> 	<p>7</p>	<p>Connect the shorter vent hose to the "IN" port. Connect the longer vent hose to the "OUT" port.</p> 
<p>8</p>	<p>Install the hose adaptors.</p> 	<p>9</p>	<p>Connect the vent from the valve cover to the "IN" port. Connect the vent from the intake to the "OUT" port.</p> 
<p>10</p>	<p>Use the zip ties to dress up the vent hoses.</p> 	<p>11</p>	<p>Install the engine cover.</p> 