





CAN-AM MAVERICK DOOR HANDLES

TOOLS REQUIRED

T-30 Drive
4mm Allen Key
1/4" Drill Bit
Box Cutter
Ruler

MATERIALS REQUIRED

<p>1</p>	<p>Remove the door handle trim bolt and pop trim piece off.</p>	<p>2</p>	<p>Remove the stock pull strap.</p>
		<p>3</p>	<p>Measure 18mm and use box cutter to create a notch in door handle trim piece.</p> 
<p>4</p>	<p>step 3 cont.</p>		
<p>5</p>	<p>6</p>	<p>7</p>	
	<p>Install door handle with provided hardware.</p> 	<p>Slightly bend the door handle mounting bracket to best align the handle w the new cut-out. Repeat on opposite side.</p> 