

CAN-AM MAVERICK FRONT CAMERA KIT

TOOLS REQUIRED

T-30 Drive
4mm Allen Key
5mm Allen Key
4mm Drill Bit
Wire Cutters
3/4" Drill Bit

MATERIALS REQUIRED

<p>1</p>	<p>Begin by removing the front cover.</p>	<p>3</p>	<p>Loosely mount camera bracket on grille.</p>
			
<p>5</p>	<p>6</p>	<p>7</p>	<p>8</p>
<p>Secure camera bracket.</p>	<p>Feed camera wire through slit in the center of the bracket.</p>	<p>Mount the camera with provided hardware.</p>	<p>Attached the camera extension wire to the camera. Using the 4mm drill bit, create mounting points to zip tie the extended camera wire.</p>
			
<p>9</p>	<p>10</p>	<p>11</p>	<p>12</p>
<p>Using the 3/4" drill bit, bore a hole on the passenger side to route the camera wire.</p>	<p>Continue feeding cable and drill two additional 4mm holes to secure camera wire.</p>	<p>Zip tie the camera wire to cable bundle and feed it through the firewall into the cabin.</p>	<p>Remove center console trim bolts.</p>
			

13	step 12 cont.	14	Connect accessory wire under front dash. If only installing camera kit then you are done! Proceed if wiring to pulse bar.	15	Remove remaining pop clips and bolts securing center console.	16	Remove remaining bolts securing shifter trim. Route wire under shifter trim piece.
							
17	Route to rear of driver seat, tuck wires away in shifter trim.	18	Plug power in to pulse bar.	19	Remove remaining pop clips and bolts securing center console.	20	Remove remaining bolts securing shifter trim. Route wire under shifter trim piece.
							
21	Reinstall interior trim pieces.	18	Reinstall front cover and you're done and ready to use your Front View Camera Kit!				
							