

CHEVY/GMC BOV ADAPTOR INSTALLATION MANUAL

TOOLS REQUIRED

M7 socket
M10 socket
M5 allen wrench
Flat screw driver

MATERIALS REQUIRED

None

1	Remove the engine cover.	2	Disconnect the vent line. Loosen the hose clamp by the air filter.	3	Disconnect the vent line and the electrical connector.	4	Loosen the hose clamp by the turbo inlet.
							
5	Disconnect the wire harness clips by the air intake.	6	Remove the nuts holding the air intake. Remove the air intake.	7	Disconnect the electrical connector. Remove the blow off valve	8	Prepare the Boomba Blow Off Valve adaptor for installation.
							
9	Line up the blow off valve with the adaptor. Insert the provided screws.	10	Place the blow off valve in the turbo housing. Secure it in position with screws. Reconnect the wire connector.	11	Reinstall the air intake and secure it to the engine. Reconnect the vent lines and the electrical connectors. Reinstall the engine cover.		
							