

22+ SUBARU WRX CATCH CAN STAGE 1

TOOLS REQUIRED

M12 Socket
Flat Screw Driver
M4 Allen Wrench
Hose Cutter

MATERIALS REQUIRED

<p>1</p>	<p>Remove the vacuum line clip.</p>	<p>2</p>	<p>Peel back hose sleeve and cut the vent line. Rotate line on the right 180 degrees.</p>
		<p>3</p>	<p>Prepare Boomba Racing Catch Can Kit.</p> 
<p>4</p>	<p>Install Boomba Racing mounting bracket.</p>	<p>5</p>	<p>Insert hose adaptors.</p> 
	<p>6</p>	<p>Remove mounting bolt furthest back on driver side of intercooler.</p> 	<p>7</p>
<p>8</p>	<p>Install Boomba Racing Catch Can.</p>	<p>9</p>	<p>Insert provided hoses. Longer hose to intake hose adaptor and "OUT" port. Shorter to the engine block hose adaptor and "IN" port.</p> 
<p>9</p>	<p>Use provided zipties to dress up hoses.</p> 		