

YAMAHA SVHO FUEL RAIL

TOOLS REQUIRED

M12 Socket
M8 Socket
Wire Cutter

MATERIALS REQUIRED

1	Remove the seat and engine cover.	2	Disconnect both sets of wire harnesses on the fuel rail and to the intake manifold.	3	Loosen fuel line hose clip.	4	Cut factory zip ties.
							
5	Unbolt stock fuel rail.	6	Make sure engine is cool and place a cloth below injector ports in case of residual fuel. Remove fuel rail.	7	Remove injectors from stock fuel rail and insert into Boomba Racing fuel rail.	8	Install Boomba Racing fuel rail and bolt down.
							
9	Resecure fuel line with hose clip.	10	Zip tie fuel rail.	11	Reconnect wire harnesses.	12	Reinstall the engine cover and seat. You are good to go!!
							